

How to do 78rpm with Pro-Ject turntables

- Pro-Ject offers turntables that are able to play 78rpm records
- Following pages show 2 charts with current and discontinued Pro-Ject turntables and their ability to play 78rpm records
- Some will do all speeds directly out of the box (A), with no additional accessory needed
- Some will need special accessories (B or C or D)
- Some turntables can not be converted for 78-use (E).
- CAUTION! Playback of 78rpm records will damage a standard stylus for 33 or 45rpm records! Special dedicated 78-needles are available for many MM cartridges! (see examples >>>)
- Drive pulley exchange can be reversed easily!
- If you are in doubt, consult your specialised Pro-Ject dealer!

Ortofon
OM 78 stylus



⇒ For playback of 78rpm records you
DEFINITELY need a dedicated stylus!

Ortofon
2M 78 stylus



A: 33 & 45 & 78

These turntables will do all speeds out of the box, no additional accessories needed



10" gramophone record 78rpm



12" LP 33rpm



7" single 45rpm

B: 33 & 78

Exchange of standard drive pulley to 78 pulley set (no 45rpm possible!)



set includes pulley and drive belt „square“

C: 33 & 45 & 78

Addition of Speed Box S and exchange of standard drive pulley to Pulley SB



D: 33 & 45 & 78

Addition of Speed Box DS and exchange of standard drive pulley to Pulley SB



Aktuelle Plattenspieler:	33/45/78 U/min ohne weiteres Zubehör	33/78 U/min (kein 45) mit "78 Pulley Set"	33/45/78 U/min mit Speed Box S & "Pulley SB"	33/45/78 U/min mit Speed Box DS & "Pulley SB"	78 U/min nicht möglich	empfohlene 78er Ersatznadel für vormontierten Tonabnehmer
	A	B	C	D	E	
1 Anny (20 Jahre PJ)/OrtSuperOM10		✓	✓	✓		OM78
1 Xpression Carbon		✓				**
1 Xpression Carbon Phono USB/Ort OM10		✓				OM78
1 Xpression Carbon/Ort 2M Red		✓				2M78
1 Xpression Carbon Classic		✓				**
1 Xpression Carbon Classic/Ort 2M Silver		✓				2M78
1 Xpression III Comfort/Ort 2M Red	✓					2M78
2 Xperience Basic +/Ort MC 25 E					✓	
2 Xperience Classic/Acryl					✓	
2 Xperience Acryl SP1/Ort Rondo Red					✓	
2 Xperience Acryl SP2/Ort Salsa					✓	
2 Xperi Classic/Acryl/Sum Blue P No. 2					✓	
2 Xperi Classic/Ort Rondo Red					✓	
2 Xperi Classic Acryl/Ort Rondo Red					✓	
2 Xperi Classic/Ort 2M Red					✓	
2 Xperi Classic Acryl/Ort 2M Red					✓	
2 Xperi Classic SP/Ort 2M Bronze					✓	
2 Xperi Classic Acryl SP/Ort 2M Bronze					✓	
2 Xperi Classic SP/Ort 2M Bronze					✓	
2 Xperi Classic Acryl SP/Ort 2M Bronze					✓	
6 PerspeX					✓	
6 PerspeX SP/Ort Valencia					✓	
6 PerspeX Anny/Ort Valencia					✓	
6 PerspeX Anny/Ort MC30SupermkII					✓	
Debut Carbon Int-DC (Basic)/Ort OM10		✓				OM78
Debut Carbon Int-DC (Basic)/PhUSB/Ort OM10		✓				OM78
Debut Carbon Int-DC (Premium)/Ort 2M Red		✓				2M78
Debut Carbon Esprit Int-DC /Ort 2M Red		✓				2M78
Debut Carbon Esprit SB-DC /Ort 2M Red	✓					2M78
Debut Carbon Int-230 volt (Basic)/Ort OM10		✓		✓		OM78
Debut Carbon Int-230 volt (Basic)/PhUSB/Ort OM10		✓				OM78
Debut Carbon Int-230 volt (Premium)/Ort 2M Red		✓		✓		2M78
Debut Carbon Esprit Int-230 volt /Ort 2M Red		✓		✓		2M78
Debut Carbon US-16 volt (Basic)/Ort OM10		✓	✓	✓		OM78
Debut Carbon US-16 volt (Basic)/PhUSB/Ort OM10		✓				OM78
Debut Carbon US-16 volt (Premium)/Ort 2M Red		✓	✓	✓		2M78
Debut Carbon Esprit US-16 volt /Ort 2M Red		✓	✓	✓		2M78
Elemental /Ort OM5E					✓	
Elemental Phono USB/Ort OM5E					✓	
Essential II Basic/Ort OM5E					✓	
Essential II Basic/Phono USB/Ort OM5E					✓	
Essential II Premium/Ort 2M Blue					✓	
Essential II Premium/Phono USB/Ort 2M Blue					✓	
Juke Box/Ort OM 5E		✓	✓	✓		OM78
Juke Box Esprit/Ort Alpha		✓	✓	✓		**
RPM 1.3 Genie/Ort OM3E					✓	
RPM 1.3 Genie/Ort 2M Red					✓	
RPM 5/Ort 2M Red		✓	✓	✓		2M78
RPM 5 SP/Ort Salsa		✓	✓	✓		**
RPM 5.1 SP/Ort 2M Blue		✓	✓	✓		2M78
RPM 5.1		✓	✓	✓		**
RPM 5.1/Ort 2M Red		✓	✓	✓		2M78
RPM 5.1 SP/PJ Pick it MC1H		✓	✓	✓		**
RPM 9.1					✓	
RPM 9.1 Acryl					✓	
RPM 9.1 SP 1/Ort Rondo Red					✓	
RPM 9.1 SP 2/Sum Blue P No. 2					✓	
RPM 9.2 Evolution					✓	
RPM 10.1 Evolution					✓	
Signature 10					✓	
Signature 12					✓	
Xtension 9 Evolution					✓	
Xtension 10 Evolution/Sum Blue P No. 2	✓					**
Xtension 10 Evolution	✓					**
Xtension 12 Evolution	✓					**

>>> Legende

A	78 U/min ohne weiteres Zubehör möglich
B	78 U/min durch Ersatz des Schwungrades durch „78 Pulley Set“ / 33 & 78 (kein 45 U/min)
C	78 U/min durch Ersatz des Schwungrades durch „Pulley SB“ und zusätzlich Speed Box S (geeignet für Plattenspieler mit 16V AC Motor)
D	78 U/min durch Ersatz des Schwungrades durch „Pulley SB“ und zusätzlich Speed Box DS (geeignet für Plattenspieler mit 16V oder 230V AC Motor)
E	78 U/min nicht verfügbar (kein Pulleytausch möglich)

Für diesen Plattenspieler nicht verfügbar

** Nur möglich, wenn passender Tonabnehmer montiert ist (Austausch des vormontierten Tonabnehmers ist möglich)

nicht mehr überall erhältlich:	33/45/78 U/min ohne weiteres Zubehör	33/78 U/min (kein 45) mit "78 Pulley Set"	33/45/78 U/min mit Speed Box S & "Pulley SB"	33/45/78 U/min mit Speed Box DS & "Pulley SB"	78 U/min nicht möglich	empfohlene 78er Ersatznadel für vormontierten Tonabnehmer
	A	B	C	D	E	
0.5		✓	✓	✓		**
0.5 Phono		✓				**
1		✓	✓	✓		**
1.2		✓	✓	✓		**
1.2.E		✓				**
1.2 C/Sum Oyster		✓	✓	✓		**
1 Xpression		✓	✓	✓		**
1 Xpression II		✓	✓	✓		**
1 Xpression II/AT 95E		✓	✓	✓		**
1 Xpression III/AT AT95E		✓	✓	✓		**
1 Xpression III C/AT AT95E		✓	✓	✓		**
1 Xpression III		✓	✓	✓		**
1 Xpression III/Ort 2M Red		✓	✓	✓		2M78
1 Xpression Classic		✓	✓	✓		**
1 Xpression Classic/Ort 2M Red		✓	✓	✓		2M78
2		✓	✓	✓		**
2 Xperience SP/OrtMC15SupmkII					✓	
2 Xperience C/Ort 510MkII					✓	
2 Xperience					✓	
2 Xperience SP1/Ort Rondo Red					✓	
2 Xperience SP2/Ort Salsa					✓	
2 Xperience Comfort/Ort 2M Red					✓	
2 Xperience Comf/Sum Blue P No. 2					✓	
2 Xperience Comfort/Ort Rondo Red					✓	
2.9 SP (Wood)/Sum Blue P No. 2		✓	✓	✓		**
2.9 Wood		✓	✓	✓		**
2.9 Classic		✓	✓	✓		**
6		✓	✓	✓		**
6.1		✓	✓	✓		**
6.9		✓	✓	✓		**
6.9 SP/Sum Blue P No.2		✓	✓	✓		**
Aspect 2011 - wie Xperience Basic +					✓	
Debut/Ort OM5E		✓	✓	✓		OM78
Debut II/Ort OM5E		✓	✓	✓		OM78
Debut II (III) Phono/Ort OM5E		✓				OM78
Debut SE II/Ort 510MkII		✓	✓	✓		**
Debut III/Ort OM5E		✓	✓	✓		OM78
Debut III E/Ort OM5E		✓	✓	✓		OM78
Debut III Phono USB/Ort OM5E		✓				OM78
Debut III Phono SB/Ort OM5E	✓					OM78
Debut III Esprit/Ort Alpha		✓	✓	✓		**
Debut SE II/Ort 510MkII		✓	✓	✓		**
Debut III SE/Ort OM10		✓	✓	✓		OM78
Essential/Ort OM5E					✓	
Essential/Phono USB/Ort OM5E					✓	
Essential Basic/Ort OM5E					✓	
Essential Basic/Phono USB/Ort OM5E					✓	
Essential Premium/Ort 2M Blue					✓	
Essential Premium/Phono USB/Ort 2M Blue					✓	
Perspective					✓	
Perspective SB					✓	
Perspective Anny/Sum Blue Point No.2					✓	
Perspective II					✓	
RPM 1 Genie/Ort OM3e					✓	
RPM 1 Genie/Ort Alpha					✓	
RPM 1 Genie/Ort 2M Red					✓	
RPM 4/Pro K4		✓	✓	✓		**
RPM 4/AT AT95E		✓	✓	✓		**
RPM 5		✓	✓	✓		**
RPM 5/Ort 2M Red		✓	✓	✓		**
RPM 5 SP/Ort Salsa		✓	✓	✓		**
RPM 5 SP/PJ Pick it MC1H		✓	✓	✓		**
RPM 5/AT AT95E		✓	✓	✓		**
RPM 5 SP/Ort X1-MC		✓	✓	✓		**
RPM 6			✓	✓		**
RPM 6 SB	✓					**
RPM 6.1 SB	✓					**
RPM 6.1 SB SP/Ort Samba	✓					**
RPM 9					✓	
RPM 9X					✓	
RPM 9XP					✓	
RPM 10					✓	
Studie					✓	